

**PILLBOX PENDANT ( E26 SOCKET )****SP-PBX-SO-10 (10")****CAUTION**

TURN OFF THE MAIN POWER AT THE CIRCUIT BREAKER BEFORE INSTALLING THE FIXTURE IN ORDER TO PREVENT POSSIBLE SHOCK

IF YOU ARE UNFAMILIAR WITH PROPER ELECTRICAL WIRING CONNECTIONS OBTAIN THE SERVICES OF A QUALIFIED ELECTRICIAN

**GENERAL**

- Read all instructions carefully for safe operation and installation.
- All electrical connections must be in accordance with local and national electrical code (N.E.C) standards.
- Remove the fixture and the mounting package from the box and make sure that no parts are missing by referencing the illustrations on the installation instruction. Please contact Blackjack Lighting if any parts are missing or damaged.
- This product is suitable for damp locations.

**INSTALLATION****PREPARATION**

1. Remove the fixture from its box.
2. Pull the supply(2&4) and house ground(6) wires out of the outlet box(1). Thread them through the large center hole in the ceiling plate(10)

**MOUNTING**

3. Place the ceiling plate(10) over the outlet box(1). Insert mounting screws(9) through the slots in the ceiling plate(10), then tightly secure them into the outlet box(1).

**ELECTRICAL CONNECTIONS**

4. Using the wire connectors(8), connect the white supply wire(2) to the white fixture wire(3); connect the black supply wire(4) to the black fixture wire(5); and connect the house ground wire(6) to the fixture ground wire(7). Tuck the wires back into the outlet box(1).

**FINAL ASSEMBLY**

5. Loosen the strain relief screw(14) and adjust the cable(15) to the desired length. Once the cable(15) is at the desired length, retighten the strain relief screw(14). Then use the included Velcro strap to retain the excess cable into neat loops that will fit inside the canopy cover(11).
6. To secure the canopy cover(11) to the ceiling plate(10) align the two holes on the bottom of the canopy cover(11) over the threaded standoffs(13) that are attached to the ceiling plate(10). Then insert the two thumbscrews(12) into the standoffs(13) and tighten them to secure everything together.
7. Insert the lightbulb(not included with the E26 socket kit) into the fixture socket.

**DIMMING**

- Fixture Dimming Type: E26 Socket: no dimming options

## HARDWARE



### Wire Connector(#8)

[ 3 Included ]




### Mounting Screw(#9)

[ 2 Included ]



### Thumb Screws(#12)

[ 2 Included ]



1. OUTLET BOX (By Others)
2. WHITE SUPPLY WIRE
3. WHITE FIXTURE WIRE
4. BLACK FIXTURE WIRE
5. BLACK SUPPLY WIRE
6. HOUSE GROUND WIRE
7. FIXTURE GROUND WIRE
8. WIRE CONNECTORS
9. MOUNTING SCREWS
10. CEILING PLATE
11. CANOPY COVER
12. THUMBSCREWS
13. THREADED STANDOFF
14. STRAIN RELIEF SCREW
15. CABLE
16. SHADE